



pcb fiducials  
 TP1 TP2 TP3

v.1.1 - VS1010-68 in library vlsi-e7 fixed -> added center pad solder paste to QFN68 -> sar2 / sar3 pinout corrected v.1.2 -crystal connection improved	<b>VS1010MiniDemo12</b> 15.5.2018 13.19 Sheet: 1/1
--	--