




## SPI Flash




## Buttons





## LEDs




## MicroSD




## Power




## SPI




## I2S




## 12V TRIG IN




## RS232




## IR



## USB



## FM



## VS1005

TITLE: vs1005amp\_v061

Document Number:

REV:

Date: 5/05/2014 09:59:40

Sheet: 1/2

XLR input voltage ranges:  
 $V_{in}=4V_{rms}$  (MUTE=1,SEL=X)  
 $V_{in}=8V_{rms}$  (MUTE=0,SEL=1)  
 $V_{in}=12V_{rms}$  (MUTE=0,SEL=0)

